


# HOW TO USE

Step-by-step guidance

## WHAT'S IN THE BOX



## WHAT CAN IT DO?

### TYPE

- 1 Yoga Book
- 2 The Halo Keyboard



### WRITE

- 1 Yoga Book
- 2 Book Pad
- 3 Real Pen w/ Ink Tip




### DRAW

- 1 Yoga Book
- 2 Create Pad
- 3 Real Pen w/ Stylus Tip



# HOW TO DIGITIZE YOUR NOTES WITH REAL PEN



- 1 Long-press the pen button
- 2 Place Book Pad on Create Pad
- 3 Use Real Pen with Ink Tip to write on paper

## TIP 1

If you are running another app, check the pen button, if it's slowly blinking it means your notes are normally digitized!

## TIP 2

Press the volume button or double tap the pen button to create a new page in Lenovo Note Saver.




# HOW TO TYPE ON THE HALO KEYBOARD

Open your Yoga Book and voila! The Halo Keyboard appears, you're ready to type.



If you're not seeing your keyboard, simply long-press the pen button, it will come back!



# HOW TO MULTITASK WITH BOOK UI

① Double tap to minimize

② Double tap to maximize

③ Slide down to close

④ Click running app icon to show or hide apps




Full screen app


Navigation keys

All apps button

Running app icon



# HOW TO CHANGE YOUR REAL PEN TIP



Use the pen cap hole to carefully pull out the tip from the Real Pen





Slide in the new tip, and you're good to go!





## HOW TO DRAW LIKE A PRO

- 1 Open the ArtRage app 
- 2 Long-press the pen button until Halo Keyboard disappears
- 3 Close the Lenovo Note Saver window that shows on screen
- 4 Make sure to always use Real Pen with the Stylus Tip
- 5 Draw like a pro!



Want to learn more?  
Check out these videos  
by scanning this QR code

